

PVCu SNAPLOCK

ref 830/832

To fit a PVCu Snaplock you will require -
 a drill, 1.5mm drill bit and a posidriv screwdriver.
(Please ensure the screws enclosed are suitable for application prior to use).

Easy fitting guide

A From inside the house, close the window and select the correct position of the PVCu Snaplock on the outward opening frame.

B Drill pilot holes using the PVCu Snaplock as a template. Drill through the frame and the inside wall of the frame. If you encounter a reinforced steel or aluminium section, drill through that section carefully so as not to touch the glass. Fix the PVCu Snaplock to the frame using suitable screws to ensure a tight fit. Once done, push the plastic screw cover over the screw head holes with a gentle push-fit.

C To ensure a tight fit of the finger to the frame when in the locked position, select a pad from those provided and press the pad into the hole provided in the finger. Take care that the fit is not so tight as to mark the PVCu frame.

Operation

- Keyed type

- Insert key into lock barrel and $1/4$ turn clockwise; the finger can then be rotated freely.
- To lock the finger across the fixed part of the frame, remove the key and place somewhere safe and out-of-sight.
- Turn the finger $1/4$ turn until a click is heard. The finger is now automatically snap-locked secure.
- To free the window to open, insert the key and $1/4$ turn clockwise. The finger is now unlocked and can be freely rotated.
- The key can now be removed by $1/4$ turning it anti-clockwise and withdrawing it.

- Keyless type

- Swing the finger over the fixed frame to stop the window opening.
- To free the window to open, swing the finger back over the fixed base.

Maintenance - use a moist cloth only, household abrasives or solvents may affect surface finish – lubrication may occasionally be required.

- ◀ Position if fitting a single lock.
- ◀ Position if fitting two locks.

