

PATIO DOOR LOCK

ref 100

To fit a **Patio Door Lock you will require** - a drill with 3mm and 12.7mm drill bits, posidriv screwdriver and pencil

Easy fitting guide

Caution: Before selecting position of lock in sliding door, ensure position will clear glass and door rolling gear.

A Close door and select position of lock.

B Locate lock mechanism, in unlocked position, 2.5mm from face of sliding frame.

Mark and drill the two 3mm diameter holes.

Do not allow drill cuttings to enter back of lock(s).

C With door still closed, push end of bolt to mark centre of hole to be drilled in frame. Open door. Drill a 12.7mm hole. Fit ferrule in hole.

Operation - push in lock barrel to lock. Turn key clockwise to open.

Security Tips - we recommend fitting Patio Door Locks at top and bottom of doors for extra security.

Maintenance - use a moist cloth only to clean all types of finish, household abrasives or solvents may affect the surface finish.

