

LOCKING WINDOW HANDLE

ref 808

To fit a Locking Window Handle you will require - a screwdriver, bradawl (or 2.5mm drill) and a pencil.
If fitting to hardwood drill 2.5mm pilot holes.

Easy fitting guide

A Remove old window handle. Fit lockable window handle in similar location. Avoid using old screw holes.

When using template on windows where hinges are on right side as you face window (reverse template) by piercing hole centres. Offer template, 'top' uppermost, with card front facing you.

Use template to mark hole positions on opening and fixed frames with bradawl.

B Screw striking plate into position on fixed frame - using packing plate if necessary. Insert key in locking handle. Turn anti-clockwise to unlock. Screw handle plate into position on opening frame.

Operation - to open, turn key clockwise and rotate handle. Remove key. Handle automatically locks on closing, and can be locked partially open for ventilation.

Security Tips - always close and lock windows fully shut, and remove keys from locks when leaving the house.

