

# METAL WINDOW LOCK

## ref 901

**To fit a Metal Window Lock you will require -**  
a drill, 3.5mm drill bit, posidriv screwdriver, pencil and masking tape.

- ◀ Indicates lock position.
- ◀ Alternative positions for greater security.

### Easy fitting guide

- A** Close window and select position of Metal Window Lock.
- B** Position lock mechanism on opening window frame. Leave a 3mm gap from the fixed window frame.  
Ensure clearance when opening window. Mark position of screw holes.
- C** Apply masking tape to drill bit and drill holes to 4mm depth.  
Caution: ensure that drill bit will not touch glass. Screw lock mechanism onto frame.

**Operation** - turn key clockwise to lock and anti-clockwise to open.

**Crime prevention tip** - for extra security, drill out the drive slots in screw head. (We recommend fitting locks to top hinged windows).

**Maintenance** - use a moist cloth only to clean all types of finish, household abrasives or solvents may affect the surface finish.

