

# WINDOW SWING LOCK

## ref 809

**To fit a Window Swing Lock you will require -**  
 a bradawl (or 2.5mm drill), posidriv screwdriver, ruler and pencil.  
 If fitting to hardwood drill 2.5mm pilot holes.

### Easy fitting guide

- A** Close window and select position of Window Swing Lock.
- ◀ Position if fitting a single lock.
  - ◀ Position if fitting two locks.
- B** Position striker plate flush with edge of fixed frame ensuring the flat face of striker plate is facing the window. Mark screw holes and screw in position.
- C** Position lock body on opening frame ensuring a 2mm gap between edge of lock body and striker plate. NB: Pivot to bottom of lock to access screw holes. Mark position of holes and screw to opening frame.

**Operation** - Swing top section of lock body over peg and screw bolt clockwise with key provided. To unlock screw bolt anti-clockwise and swing top section of lock body clear of peg.

**Safety Tip** - for child safety fit ERA Window Restrictor Ref: 720, to restrict full opening.

**Security Tips** - fit swing lock at top and bottom of window for maximum security and draught reduction. Always close and lock windows, and remove key from locks when leaving the house.

