

MULTI PURPOSE DOOR BOLT

ref 807

To fit a Multi Purpose Bolt you will require - a drill and 4mm, 11mm drill bits (aluminum doors) or 13mm (wooden doors) mallet and chisel, posidriv screwdriver and a pencil.

If fitting to hardwood drill 2.5mm pilot holes.


ALUMINIUM PATIO DOOR - SLIDING

Easy fitting guide

A Close door and position unlocked Multi Purpose Bolt on door. Gently tap bolt end to mark position on fixed frame. Drill an 11mm hole in fixed frame. With bolt in locked position locate lock body as high as possible on frame whilst allowing free movement of the door when unlocked. Ensuring that the bolt sits at least to depth of groove in to drilled hole (when locked) mark screw hole positions.

Caution: ensure that drill bit will not touch glass.

Drill 4mm pilot holes and screw lock body to door frame with the 'thick' 25mm crosshead screws. Check operation of lock. Insert plastic plugs in lock body screw holes.



WOODEN DOOR - HINGED

Easy fitting guide

A Close door and select position of Multi Purpose Bolt(s).




B Recessed Doors

Hold lock body, unlocked, on door. Push bolt upwards to mark hole position on frame. Drill a 13mm hole in frame.

Tap in ferrule or use small receiver plate with the thin 25mm crosshead screws. Hold lock body, in locked position, with bolt in hole. Mark lock body hole position on door. Use 'thick' 38mm crosshead screws to secure lock body to door frame. Check operation of lock. Insert plastic plugs in lock body screw holes.

C Flush Doors

Select either the large flat or angled receiver plate as required. Hold lock body on door and line up with selected receiver plate. Mark lock body hole positions and screw to door with 'thick' 38mm crosshead screws. Position selected receiver plate on frame. Mark hole positions and screw to frame. Use 'thin' 25mm crosshead for large flat receiver plate and security screws for angled plate.



WOODEN PATIO DOOR - SLIDING

Easy fitting guide

A Fit as above instructions but drill a 13mm hole in frame to accept ferrule which should be tapped into position or use the small receiver plate, recessing if necessary (with 'thin' 25mm crosshead screws). Use the 'thick' 38mm crosshead screws to secure lock body to door frame.

Operation - push bolt to lock turn key anti-clockwise to unlock.

Maintenance - use a moist cloth only to clean all types of finish, household abrasives or solvents may affect the surface finish.

