




Traditional Door Lock 60mm Backset

To fit the Front Door Lock you will require -

a drill, 32mm drill bit, hacksaw, mallet, chisel, posidriv screwdriver and pencil


Fig 1



Easy Fitting Guide


Select desired height for lock. Mark centre of cylinder hole 60mm from edge of door. Drill a 32mm (1 1/4") diameter hole through door. Fig 1

Fig 2




Insert cylinder into ring and push through the door. With a pencil, mark cylinder bar level with inside of surface of door. Remove cylinder and cut bar so that it will project 10-12mm beyond the door face, i.e. beyond the pencil mark. Fig 2

Fig 3




Hold backing plate against door, ensuring the bevelled side sits in the hole. Insert connecting bolts through backing plate holes, into cylinder. Fig 3

Fig 4




Locate lock body onto backing plate. Ensure flat connecting bar of cylinder is inserted into the slot on the back of the lock body. Mark area of wood to be chiseled out to accommodate the lip on the face of the lock body, so that the lock face is flush against the door edge. Fig 4

Fig 5




Re-locate lock and insert 3 wood screws provided to fix lock body, drilling pilot holes if necessary. Fig 5

Fig 6



Close door, and mark position of staple, using lock as guide. Mark area of wood to be removed and chisel out. Fig 6

Fig 7



Insert 3 wood screws provided to fix staple, drilling pilot holes if necessary. Fig 7